



We invented the popcorn machine
THEN JUST KEPT GOING!

176 MITTEL DRIVE, WOOD DALE, IL 60191

ROC N'ROLL™ WARMER OPERATION MANUAL

120 Volt,
Single Phase, 60 Hz

230 Volt,
Single Phase, 50 Hz



READ and **UNDERSTAND** these operating and safety
instructions before operating this machine

CRETORS CUSTOMER SERVICE - 800-228-1885
773-588-1690

SAFETY FIRST



The information in this manual is essential for the safe installation and maintenance of your Roc N' Roll™ Warmer. The manual must be read and understood before installing, operating or maintaining this equipment or equivalent training must be provided.



"The employer shall instruct each employee in the recognition and avoidance of unsafe conditions and the regulations applicable to his work environment to control or eliminate any hazards or other exposure to illness or injury".
Ref.: 29 CFR 1926.20 (b)(4)(a)(2)

I INTRODUCTION

This manual contains information regarding your Roc N' Roll™ Warmer. There is nothing, however, more important than the safety aids and warnings that are found throughout this document. The Safety Alert Symbol is used to identify topics of primary safety concern wherever they appear. Furthermore, a separate section has been included which deals exclusively with operation and accident prevention.

If, after reviewing this manual, anything is unclear or technical problems are encountered, contact the dealer from whom you purchased your machine for assistance; and, if there are any additional questions, feel free to contact our Customer Service Department at 800/228-1885. Always have the serial number of your machine available to assist in obtaining the correct information.

II SAFETY ALERT SYMBOL

The symbol shown below is used to call your attention to instructions concerning your personal safety and the safety of others. Watch this symbol. It points out important safety precautions. It means "ATTENTION! Become Alert! Your personal safety is involved!" Read the message that follows and be alert to the risk of personal injury or death.



III PURPOSE OF MANUAL



This instruction manual is intended to familiarize owners with the operation and safety procedures associated with your Roc N' Roll™ Warmer.



This manual should be kept available to operating and maintenance personnel.



A person who has not read and understood all operating and safety instructions is not qualified to operate the machine.

IV PRODUCT IDENTIFICATION

CRETORS ROC N' ROLL™ (ROLL OUT CORNDITIONER) WARMER

MODEL	7919 ROC N' ROLL™ WARMER (WITH LIGHTS)
--------------	---

Electrical:	120 Volt, Single Phase, 60 Cycle, 1310 Watts
-------------	--

Dimensions:	30 ½" H x 30" W x 26" D
-------------	-------------------------

Net Weight:	140 lbs. (63.5 kg)
-------------	--------------------

MODEL	7920 ROC N' ROLL™ WARMER
--------------	---------------------------------

Electrical:	120 Volt, Single Phase, 60 Cycle, 1250 Watts
-------------	--

Dimensions:	30 ½" H x 30" W x 26" D
-------------	-------------------------

Net Weight:	140 lbs. (63.5 kg)
-------------	--------------------

MODEL	7919-E ROC N' ROLL™ WARMER (WITH LIGHTS)
--------------	---

Electrical:	230 Volt, Single Phase, 50 Cycle, 1310 Watts
-------------	--

Dimensions:	30 ½" H x 30" W x 26" D
-------------	-------------------------

Net Weight:	140 lbs. (63.5 kg)
-------------	--------------------

MODEL	7920-E ROC N' ROLL™ WARMER
--------------	-----------------------------------

Electrical:	230 Volt, Single Phase, 50 Cycle, 1250 Watts
-------------	--

Dimensions:	30 ½" H x 30" W x 26" D
-------------	-------------------------

Net Weight:	140 lbs. (63.5 kg)
-------------	--------------------

V **THEORY AND OBSERVATIONS OF WARMER OPERATION**

The Roc N' Roll™ Warmer is designed to transport 64 servings (15 lbs.) of freshly popped popcorn directly from the machine to the concession area or docking station.

Maximum transportation load rating: 30 lbs (13.6 Kg)

VI **CONTROL SWITCH**

CORNDITIONER SWITCH	-Turns cabinet heat ON/OFF
---------------------	----------------------------

LIGHT SWITCH	-Turns cabinet light ON/OFF
--------------	-----------------------------

VII **INSTALLATION INSTRUCTIONS**

1. **Location**

Choose a location for your Roc N' Roll™ Warmer to maximize the ease of operation and maintenance procedures. Check your local building and fire codes for location restrictions.

2. **Power Supply**

Check the nameplate to determine the required power supply.



Connect your warmer only to the correct power source.



Make certain the Rocker Switches on the warmer are in the 'OFF' position when plugging and unplugging into power source.

3. After Connecting Warmer to Power Supply

The unit's operation can be controlled by the backlit rocker switch located on the front lower right-hand side of the warmer.

VIII OPERATING INSTRUCTIONS



Plug Roc N' Roll Warmer into docking station, Cretors Pop N' Roll popcorn machine, or with authorized Cretors plug and cord combination.

1. Lights are turned ON by pressing the top rocker switch to its ON position. Switch will be marked "Lights".
2. Cabinet heat is turned ON by pressing the bottom switch to its ON position. Switch will be marked "Conditioner".



Operate your warmer only under sanitary condition (SANITATION INSTRUCTIONS).

For service technician: To replace the halogen bulb, make sure the machine is unplugged. Then remove the bulb from the mounting bracket and pull out old bulb from socket. Install new bulb by pushing bulb pins into socket, and inserting bulb back into the mounting bracket.

VIII SANITATION INSTRUCTIONS



Be certain the machine is turned 'OFF' and power is unplugged before sanitizing or performing any maintenance on this machine. Failure to do so could result in injury.



The clean out drawer, located on the operator side of the warmer, should be cleaned daily. This is done by simply pulling the drawer completely out of the warmer and dumping scrap into the garbage.

The screens can be removed and cleaned by simply pulling upward on the recessed handles.



CAUTION: HOT! Do not clean **appliances** until they have been given sufficient time to cool. Failure to do so may result in serious burns.

The cabinet is **to** be cleaned **with a damp cloth** and any good grade glass or household cleaner suitable for stainless steel surfaces. A cleaning agent that is acceptable for food contact surfaces is recommended. **Do not soak unit with water. Avoid wetting of inside of electrical enclosure.**

This appliance(s) shall not be cleaned with a water jet.

SAFETY FIRST



The information in this manual is essential for the safe installation and maintenance of your Roc N' Roll™ machine. The manual must be read and understood before installing, operating or maintaining this equipment or equivalent training must be provided.



"The employer shall instruct each employee in the recognition and avoidance of unsafe conditions and the regulations applicable to his work environment to control or eliminate any hazards or other exposure to illness or injury". Ref.: 29 CFR 1926.20 (b)(4)(a)(2)



It is understood that safety rules within individual companies vary. If a conflict exists between the safety procedures contained in this manual and the rules of a using company, the more stringent rule should take precedence.


This manual is filled with timesaving and money-saving information regarding your Roc N' Roll™ Warmer. There is nothing, however, more important than the safety aids and warnings found throughout this document.


If you have any questions, feel free to contact our Customer Service at 800/228-1885.

Additional copies of this manual can be obtained from Customer Service.



Cretors warranties this machine to be free of defects in parts, materials and workmanship for two years. Please fill out and return the registration card to activate your warranty. If you have questions concerning the warranty, please contact Customer Service at 800/228-1885.







1194	BLOWER - 240V
1207	ELEMENT 1250 WATT
1220	BLOWER - CORNDITIONER - 120V
1727-A	ELEMENT 1100 WATT, 120 VOLT-TUBE
5130	SWITCH-LIGHTED - 230V
5601	HIGH LIMIT 200°F
5602-A	TRANSFORMER-100W,120V-12V
10844	TRANSFORMER - 100W, 120V/230V-12V/24V (WORKS FOR BOTH 120V & 230V)
10864	THERMOSTAT - 145 F
1190-5	ELEMENT CLAMP
12118	DECAL-SWITCHPLATE
12167	HI LIMIT 200°F - ALL POLE DISCONNECT (230V)
12170	HEAT BOX
12171	HEAT BOX COVER



ROC N' ROLL - FRONT & REAR VIEW

BEGINNING SERIAL NO. 00015930

DOC RNR30002

RNR-3.0-A

04/05

1294 HANDLE - LIFT
5130 SWITCH - LIGHTED - 230V
6012 DECAL-CAUTION
10829 CORNDITIONER SCREEN
12060 BUMPER
12079 PLEXI-WINDOW
12081 PLUG-15A NEMA, 3WIRE
12085 CASTER - W/ BRAKE
12086 CASTER - W/O BRAKE
12090 CLEAN OUT DRAWER
12118 DECAL - SWITCHPLATE
12195 BIN COVER SET - 2 PC.

NOT SHOWN

12093 BIN COVER SET- 3 PC. (REPLACED JAN. 2000)
12116 CORD SET
12116-E CORD SET - EXPORT
12371 CORD - STRAIGHT 15AMP W/ MALE & FEMALE

C. CRETORS AND COMPANY

176 MITTEL DRIVE

WOOD DALE, IL 60191

PHONE: (847)616-6900, (800)228-1885, FAX: (847)616-6970

WEB SITE: <http://www.cretors.com>