



We invented the popcorn machine  
THEN JUST KEPT GOING!

---

**176 MITTEL DRIVE, WOOD DALE, IL 60191**

---

**Models: E1202  
Nacho Pequeño**

## **Display Cabinet Manual**

**100 Volt, Single Phase, 50/60 Hz  
120 Volt, Single Phase, 60 Hz (-A)  
230 Volt, Single Phase, 50 Hz (-E)**



**READ and UNDERSTAND these operating and safety instructions before operating this Cretors machine**

**TABLE OF CONTENTS**

- I. Safety Alert Symbol ..... 3
- II. Safety First ..... 3
- III. Introduction..... 3
- IV. Purpose of Manual ..... 4
- V. Product Identification ..... 4
- VI. Principles of Display Cabinet Operation..... 4
- VII. Control Switch ..... 4
- VIII. Installation Instructions ..... 4
- IX. Operating Instructions ..... 5
- X. Sanitation Instructions ..... 5
- XI. Service Instructions ..... 6
- XII. Troubleshooting..... 6

---

## I. SAFETY ALERT SYMBOL

The symbol shown is used to call your attention to instructions concerning your personal safety and the safety of others. Watch for this symbol. It points out important safety precautions. It means **ATTENTION! Be Alert! Your personal safety is involved!** Read the message that follows and be alert to the risk of personal injury or death.



---

## II. SAFETY FIRST



The information in this manual is essential for the safe installation and operation of your Cretors machine. The manual must be read and understood before installing, and operating the equipment, or equivalent training must be provided.



The employer shall instruct each employee in the recognition and avoidance of unsafe conditions, as well as, the regulations applicable to his work environment and to control or eliminate any hazards or other exposure to illness or injury. Ref.: 29 CFR 1926.20 (b)(4)(a)(2)



It is understood that safety rules within individual companies vary. If a conflict exists between the safety procedures contained in this manual and the rules of a using company, the more stringent rule should take precedence.

---

## III. INTRODUCTION

This manual is filled with time-saving and money-saving information regarding your unit. There is nothing more important than the safety aids and warnings that are throughout this document. The Safety Alert Symbol is used to identify topics of primary safety concern wherever they appear.

If, after reviewing this manual, anything is unclear or technical problems are encountered, contact the distributor from whom you purchased your unit for assistance or contact our Customer Service Department at (800) 228-1885. Always have the model and serial number of your unit available to assist in obtaining the correct information.

#### IV. PURPOSE OF MANUAL

This instruction manual is intended to familiarize owners with the operation and safety procedures associated with the unit.

It is important that this manual be kept available to operating personnel.

#### V. PRODUCT IDENTIFICATION

CRETORS POPCORN AND NACHO DISPLAY CABINET

MODEL	NPA_-X; NPE_-X –DISPLAY CABINET REF. (1202-A/1202-E –DISPLAY CABINET)
-------	--

Electrical:	100 Volt, 50/60 Cycle, 160 Watts
	120 Volt, 60 Cycle, 160 Watts
	230 Volt, 50 Cycle, 160 Watts

#### VI. PRINCIPLES OF DISPLAY CABINET OPERATION

##### Theory and Observations of Display Cabinet Operation

The Display Cabinets hold nacho chips, popcorn, or other snacks on racks to maximize the sell ability of snacks. Load and un-load product through the large door on the unit's front. The unit features a corrosion-resistant design and tempered glass for easy cleaning; the surface will not scratch or discolor. The unit's door is easily-removable, for cleaning. Rubber feet prevent skidding on counter top surfaces. The cabinet is provided with two lights and a heat pad to keep product warm.

#### VII. CONTROL SWITCH

MAIN POWER SWITCH	-Controls light and cabinet heat.
-------------------	-----------------------------------

#### VIII. INSTALLATION INSTRUCTIONS

##### 1. Location

Choose a location for your unit to maximize the ease of operation and maintenance procedures. Check your local building and fire codes for location restrictions.

##### 2. Power Supply

Check the nameplate to determine the required power supply.



Connect the unit only to the correct power source.



Make certain the main power switch on the cabinet is in the 'OFF' position when plugging into power source.

### 3. Install the racks

Install the clips in all four corners at the same height, as desired. The unit is provided with two (2) racks and eight (8) clips which can be installed to accommodate different size packaging.

---

## IX. OPERATING INSTRUCTIONS



Do not attempt to operate the unit until you have read and understood this manual. Failure to do so may result in serious injury or death.



Do not attempt to operate your unit unless the installation instructions have been strictly adhered to. Failure to do so may result in serious injury or death.



Operate the unit only if it is in sanitary condition (SANITATION INSTRUCTIONS). Failure to do so may result in illness to your customers.

1. Turn on rocker switch to turn on light and heat pad.
2. With racks already installed at desired height, load unit with product. Do not overfill the cabinet.
3. Dispense product through the front door. Door can be installed on opposite side to open opposite direction.

---

## X. SANITATION INSTRUCTIONS



Be certain the unit is turned off and the power is unplugged before sanitizing, unless a specific cleaning procedure requires power to the machine. Failure to do so could result in serious injury or death.



Do not clean heated surfaces until they have been given sufficient time to cool. Failure to do so may result in serious burns or scalds.



Do not immerse the unit in water. This will damage the electrical components, and may cause short circuits, resulting in an electrical shock hazard if power is applied.

1. After unit has been allowed to cool and has been unplugged, remove any excess product remaining in the bottom.
2. Clean all surfaces with a non-abrasive food safe cleaner.



This appliance should not be cleaned with a water jet.

## XI. SERVICE INSTRUCTIONS



Only a qualified person should perform the following diagnostic checks, and, if necessary, corresponding adjustments and repairs. Many of the following procedures may present an electrical shock hazard and can cause serious injury or death.



Perform work only on de-energized circuits. Failure to do so may lead to electrical shock resulting in personal injury or death.

### A. Parts

When ordering parts, refer to the recommend spare parts list included with this manual or wiring diagram. Always supply the serial number and model number of the unit.

### B. Check Unit Periodically

Periodically check electrical switch and cord for signs of wear. Check all screws and rivets for tightness.

### C. To Access Electrical Components

To access all electrical components, unplug power cord from outlet, and then lay unit on its side and remove the four screws from the bottom cover, exposing heating element, switch, and wiring. **THIS UNIT IS NOT FUSED.**

### D. Troubleshooting

PROBLEM	POSSIBLE CAUSE	ACTION
Unit will not heat.	Unit unplugged or not switched on.	Plug unit in. Turn on power.
	Loose connection to heater.	Repair connection.
Light will not work.	Unit unplugged or not switched on.	Plug unit in. Turn on power.
	Bulb burned out.	Replace bulb with recommended replacement part (#EP2053-220)

## RECOMMEND SPARE PARTS LIST

PART DESCRIPTION	PART NUMBER
------------------	-------------

DOOR HINGE	EP4866
LIGHT BULB	EP2053-220
CLIP	16807
RACK	16810
DOOR	EP1904
KNOB	EP4539
MAGNET	EP1820

This unit is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the unit by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the unit.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

If you have questions regarding the operation or cleaning of your unit, contact your local distributor or the Customer Service Department at C. Cretors and Company at (800) 228-1885.

Cretors guarantees this machine to be free of defects in parts, materials and workmanship for two years. Please fill out the factory registration card and return it to activate your warranty. If you have questions concerning the Cretors' warranty, please contact your local distributor or the Customer Service Department at C. Cretors and Company.



C. CRETORS AND COMPANY  
 176 MITTEL DRIVE  
 WOOD DALE, IL 60191  
 PHONE (800) 228-1885, FAX (847) 616-6970  
 WEB SITE: <http://www.cretors.com> Email: [postmaster@cretors.com](mailto:postmaster@cretors.com)