

176 MITTEL DRIVE, WOOD DALE, IL 60191

BULK WARMER / NACHO WARMER & PORTION PAK WARMER SERVICE / OPERATION MANUAL

120 Volt, Single Phase, 60 Hz

100/120 Volt, Single Phase, 50/60 Hz

230 Volt, Single Phase, 50 Hz



<u>READ</u> and <u>**UNDERSTAND**</u> these servicing, and safety instructions before servicing this machine

SAFETY FIRST



The information in this manual is essential for the safe installation and maintenance of your Cretors warmer. The manual must be read and understood before installing, operating or maintaining this equipment, or equivalent training must be provided.



"The employer shall instruct each employee in the recognition and avoidance of unsafe conditions and the regulations applicable to his work environment to control or eliminate any hazards or other exposure to illness or injury". Ref.: 29 CFR 1926.20 (b)(4)(a)(2)



It is understood that safety rules within individual companies vary. If a conflict exists between the safety procedures contained in this manual and the rules of a using company, the more stringent rule should take precedence.

I INTRODUCTION

This manual is filled with time-saving and money-saving information regarding your Cretors warmer. There is nothing, however, more important than the safety aids and warnings that are found throughout this document. The Safety Alert Symbol is used to identify topics of primary safety concern wherever they appear. Furthermore, a separate section has been included which deals exclusively with operation and accident prevention.

If, after reviewing this manual, anything is unclear or technical problems are encountered, contact the dealer from whom you purchased your machine for assistance and if there are any additional questions, feel free to contact our Customer Service Department at the address and/or phone number listed on the back cover of this manual. Always have the model and serial number of your machine available to assist in obtaining the correct information.

II SAFETY ALERT SYMBOL

The symbol shown below is used to call your attention to instructions concerning your personal safety and the safety of others. Watch this symbol. It points out important safety precautions. It means "ATTENTION! Become Alert! Your personal safety is involved!" Read the message that follows and be alert to the risk of personal injury or death.



III PURPOSE OF MANUAL



This instruction manual is intended to familiarize owners with the operation, servicing and safety procedures associated with your Cretors warmer.



This manual should be kept available to operating and maintenance personnel.



A person who has not read and understood all operating and safety instructions is not qualified to operate the machine.

IV PRODUCT IDENTIFICATION

CRETORS BULK, NACHO AND PORTION PAK WARMER

ELECTRICAL SPECIFICATIONS: Bulk, Nacho and Portion Pak Warmers are available in any of the following Electrical configurations: 120 Volt, Single Phase, 60 Cycle

100/120 Volt, Single Phase, 60 Cycle 230 Volt, Single Phase, 50 Cycle

SPECIFICATIONS:

MODEL TW/BW	BULK / NACHO WARMERS
Electrical:	450 watts
Dimensions:	18-3/4"D x 18-3/4"W x 26" H 47.6 cm D x 47.6cm W x 66 cm H
Net Weight:	51 lbs. (23 kg.)
MODEL PPW	PORTION PAK WARMER
Electrical:	425 watts
Dimensions:	16-5/8"D x 13"W x 18-7/8" H 42.2 cm D x 33.0cm W x 47.9 cm H
Net Weight:	40 lbs. (18 kg.)

V THEORY AND OBSERVATIONS OF WARMER OPERATION

The Bulk, Nacho and Portion Pak Warmer is designed to warm and display pre-packaged cheese and chip products. The unit is designed with a heating element and blower to circulate warmed air in the cabinet.

Adjustable wire shelves and a backlit sign compliment the Bulk and Nacho Warmer unit for display purposes.

The Portion Pak Warmer has wire shelves and a backlit sign.

VI CONTROL SWITCH

ROCKER SWITCH -Turns light and cabinet heat ON/OFF

VII INSTALLATION INSTRUCTIONS

1. Location

Choose a location for your Cretors machine to maximize the ease of operation and maintenance procedures. Check your local building and fire codes for location restrictions.

2. Power Supply

Check the nameplate to determine the required power supply.



Connect your warmer only to the correct power source. Failure to do so may result in personal injury or death and may damage your warmer.



Make certain the Rocker Switch on the warmer is in the 'OFF' position when plugging into power source. Failure to do so may result in personal injury or death and may damage your warmer.

3. After Connecting Warmer to Power Supply

The unit's operation can be controlled by the backlit rocker switch located above the plexiglass door.

VIII SERVICE INSTRUCTIONS



In the case of improper operation, qualified personnel only should perform the following diagnostic checks, and, if necessary, corresponding adjustments and repairs. Many of the following procedures present an electrical shock hazard and can cause serious injury or death.

1. Parts

When ordering parts, refer to the attached parts diagram. Always supply the serial number, model number, and voltage of your warmer.

IX TROUBLE SHOOTING

1. Problem - Cabinet Will Not Heat

QUESTION: Do any of the other components work - blower, light, etc.?

NO! Check power supply:

- A. Is it plugged in?
- B. Is the receptacle live?
- C. Is machine plugged into the proper voltage? Measure with voltmeter and compare to specification on nameplate of machine.



Do not attempt electrical repairs on the power supply circuit unless you are qualified to do so. The electrical shock associated with line voltages can cause serious injury or death.

YES!

A. Problem is in machine.

If blower runs, but air is cold, check the two thermostats and heat element. To check the thermostats and heat element, perform the following operations:

- A) Unplug machine.
- B) To gain access to the top thermostat on the Portion Pak and both thermostats on the Nacho Warmer, remove the top of the machine by removing the screws on the top.

On the Portion Pak, to gain access to the bottom thermostat and element, remove the front sign and perforated wire guard on the inside.

C) Using a multimeter, check the continuity between the terminals of each thermostat. Remove wire. If reading is not equal to '0' ohms, the thermostat is faulty. Replace thermostat.

D) Using multimeter, check continuity of the heat element. Remove the wire from one terminal. The meter should read 36 Ω (ohms) for 120 volt or 144 Ω for 230-volt machine. Replace the heat element.

If blower does not run, perform the following operation:

- A) Unplug machine.
- B) Remove the top of the machine by removing the screws at the top.
- C) Remove sign.
- D) Using a multi meter, check Ohm on the motor. If the reading is equal to '0" or infinite (∞) Ohm (Ω), replace the motor.

X OPERATING INSTRUCTIONS



1. Do not attempt to operate your Cretors warmer until you have read and understood this manual. Failure to do so may result in serious injury or death.



2. Do not attempt to operate your Cretors warmer unless the installation instructions have been strictly adhered to. Failure to do so may result in serious injury or death.

3. This warmer is designed to warm pre-packaged aseptic sealed food products. Failure to use prepackaged sealed products may result in illness to your customers.

4. Place prepackaged food products on wire shelves.

5. Turn 'ON' rocker switch located above the plexiglass doors.

6. Allow sufficient time for unit to warm prepackaged food products before serving to customers.



7. Operate your warmer only if it is in sanitary condition (SANITATION INSTRUCTIONS). Failure to do so may result in illness to your customers.

XI SANITATION INSTRUCTIONS



Be certain the machine is turned 'OFF' and power is unplugged before sanitizing this machine. Failure to do so could result in injury or death.



Do not clean heated surfaces until they have been given sufficient time to cool. Failure to do so may result in serious burns.

The cabinet can be cleaned with any good grade glass or household cleaner suitable for stainless steel surfaces. A cleaning agent that is acceptable for food contact surfaces are recommended.

SAFETY FIRST



The information in this manual is essential for the safe installation and maintenance of your Cretors machine. The manual must be read and understood before installing, operating or maintaining this equipment, or equivalent training must be provided.



"The employer shall instruct each employee in the recognition and avoidance of unsafe conditions and the regulations applicable to his work environment to control or eliminate any hazards or other exposure to illness or injury". Ref.: 29 CFR 1926.20 (b)(4)(a)(2)



It is understood that safety rules within individual companies vary. If a conflict exists between the safety procedures contained in this manual and the rules of a using company, the more stringent rule should take precedence.

This manual is filled with time-saving and money-saving information regarding your Cretors machine. There is nothing, however, more important than the safety aids and warnings found throughout this document.


If you have any questions, contact your local dealer and if there are any additional questions, feel free to contact the Customer Service Department at C. Cretors and Company.

Additional copies of this manual can be obtained from C. Cretors and Company at the address listed below. Please provide model and serial number when requesting additional copies of this manual. There will be a nominal charge for additional copies.

Cretors guarantees this machine to be free of defects in parts, materials and workmanship for two years. Please take this time to fill out the factory registration card and return it to the factory to activate your warranty. If you have any questions concerning the Cretors' warranty, please contact your local dealer or the Customer Service department at C. Cretors and Company.



THEN JUST KEPT GOINGI C. CRETORS AND COMPANY 176 MITTEL DRIVE WOOD DALE, IL 60191 PHONE (773) 588-1690, (800) 228-1885, FAX (773) 588-7141 WEB SITE: http://www.cretors.com Email: postmaster@cretors.com




	ARMER - 100V/120V/230V IG SERIAL 00010187	DOC: T
1153	DOOR HINGE - STRAP ONLY	
1154	DOOR HINGE & STRAP- LEFT	
1155	DOOR HINGE & STRAP- RIGHT	
1154-2	HINGE - LEFT ONLY	
1155-2	HINGE - RIGHT ONLY	
1292	KNOB - CONCAVE W/ SCREW	
1605	RUBBER FOOT W/ HARDWARE	
1757	CHANNEL-GLASS "U" - SOLD PER FOOT	
1788	CORD 10 AMP 16-3 NEMA 5-15P	
2852	CORD SET-EUROPEAN	
3856	SS GLASS CHANNEL - SIDES	
4922	SWITCH-SMALL ROCKER	
5274	TOP-NACHO WARMER	
5276	PLEXI - DOOR	
5278	SIDE GLASS 16-15/16" x 14-1/8" x 1/8" (43 cm x 35.88 cm x .32 cm) (NOT AVAILABLE FROM	SHOP)
5279	FRONT GLASS 16-15/16" x 16-3/4" x 1/8" (43 cm x 42.55 cm x .32 cm) (NOT AVAILABLE FROM	SHOP)
5280-1	SS CHANNEL - FRONT	
5281	RACK- WIRE	
5406	DECAL - NACHO WARMER	
5407-L	FRONT INSIDE CORNER	
5407-R	FRONT INSIDE CORNER	
5720	SIGN RETAINER BRACKET	
5829	#6 x ½ PHILLIPS HEAD	
7654	10-24 x 3/8 BH W/ NYLOCK	
7802	10-24 x 1/4 BH W/ NYLOCK	
7804	#6 x 12 SLTD PAN SHEET METAL	
10481	MAGNETIC CATCH RECTANGULAR	
12460-L	AIR DUCT-LEFT	

12635-1 CLEAN OUT DRAWER

NOT SHOWN

- 12460-R AIR DUCT-RIGHT
- 2166 CORD GRIP
- 5474 PLEXI SIGN BACKING
- 12451 DECAL PEANUTS
- 12656 DECAL SNACKS

TRAY WARMER - 120V/230V BEGINNING SERIAL 99030000



1410 BALLAST 20 WATT 1821 SOCKET-FLUORESCENT LAMP HOLDER-COMB. 2062 2121 BUSHING **TERMINAL BLOCK** 2265 THERMOSTAT 5198 5275 LIGHT REFLECTOR 5282 LAMP-FLUORESCENT 5285 PLEXIGLASS LIGHT COVER 5283-E **BALLAST 230V** 5338-A **BLOWER MOTOR** 5338-E **BLOWER MOTOR** 5461 LIGHT COVER 5504 8-32 HX SERRATED FLANGE NUT


5608 STARTER 5700 MOTOR MOUNT PLATE 5714 **BLOWER FAN** 7637 8-32 1/2 SS. TRUSS HEAD 8-32 x 3/8 SS. TRUSS HEAD 7642 7653 8-32 HEX NUT 7683 3/16 SAE FLAT WASHER 7789 #8 STAR LOCKWASHER

NOT SHOWN 4860 BLOWER WHEEL 4858-E HEAT ELEMENT

C. CRETORS AND COMPANY 176 MITTEL DRIVE WOOD DALE, IL 60191 PHONE: (847)616-6900, (800)228-1885, FAX: (847)616-6970 WEB SITE: http://www.cretors.com Email: postmaster@cretors.com NACHO/BULK WARMER/TRAY WARMER WIRING DIAGRAM - 120V 60Hz BEGINING SERIAL NO. 1908

DOC: NWAr1

08/2019



C.CRETORS AND COMPANY 170 MITTEL DRIVE WOOD DALE, ILLINOIS 60191 PHONE(847)616-6900, (800)228-1885, FAX (847)616-6970 WEB SITE: http://www.cretors.com Email: postmaster@cretors.com DOC: NWAr1